

Repair Capability List

Weather Radar Systems

Honeywell RDS-81/82/86
Honeywell RDR-160
Honeywell RDR-2000/2100
Bendix1200/1300/1400
Sperry P-90
Collins WXR-200/220/270/300

Rockwell Collins

622-2506-XXX RMI-36 NAV INDICATOR
622-2855-XXX ALT-55B RADIO ALTIMETER
622-2937-XXX ALI-55 RADIO ALTIMETER INDICATOR
622-2938-XXX ALI-55A RADIO ALTIMETER INDICATOR
622-4160-XXX DRI-55 RADIO ALTIMETER INDICATOR
622-5367-XXX ALI-55B RADIO ALTIMETER INDICATOR
622-6137-XXX VIR-32 NAV RECEIVER
622-6152-XXX VHF-22A VHF TRANSCEIVER
622-6153-XXX VHF-22B VHF TRANSCEIVER
622-6263-XXX DME-42 DME TRANSCEIVER
622-6389-XXX VHF-21A VHF TRANSCEIVER
622-6390-XXX VHF-21B VHF TRANSCEIVER
622-6520-XXX CTL-22 COMM CONTROLLER
622-6521-XXX CTL-32 NAV CONTROLLER
622-6522-XXX CTL-62 ADF CONTROLLER
622-6523-XXX CTL-92 XPDR CONTROLLER
622-6524-XXX IND-42A DME INDICATOR
622-7194-XXX VIR-432 NAV RECEIVER
622-7292-XXX VHF-422A VHF TRANSCEIVER
622-7318-XXX IND-42C DME INDICATOR
622-7382-XXX ADF-462 ADF RECEIVER
622-8737-XXX CTL-22A COMM CONTROLLER
622-8738-XXX CTL-32A NAV CONTROLLER
622-8739-XXX CTL-62A ADF CONTROLLER
622-8740-XXX CTL-92A XPDR CONTROLLER
622-9976-XXX IND-42M DME INDICATOR
622-2362-XXX ADF-60A ADF RECEIVER
622-2873-XXX ADF-60B ADF RECEIVER

622-6590-XXX	CAD-62 ADF CONVERTOR
522-4088-XXX	618M-2B VHF COMM
522-4089-XXX	618M-2D VHF COMM
622-1181-XXX	618M-3 VHF COMM
622-1396-XXX	618M-3A VHF COMM
822-0731-XXX	618M-4 VHF COMM
822-0732-XXX	618M-4A VHF COMM
622-3255-XXX	51RV-4 NAV RECEIVER
622-3257-XXX	51RV-4B NAV RECEIVER
622-3259-XXX	51RV-4D NAV RECEIVER
822-0760-XXX	51RV-5 NAV RECEIVER
822-0761-XXX	51RV-5B NAV RECEIVER
822-0762-XXX	51RV-5D NAV RECEIVER
522-4280-XXX	51RV-2B NAV RECEIVER
522-4977-XXX	51RV-2B NAV RECEIVER
522-2450-XXX	51RV-1 NAV RECEIVER
787-6211-XXX	621A-6 TRANSPONDER
622-2224-XXX	621A-6A TRANSPONDER
522-2703-XXX	621A-3 TRANSPONDER
522-2996-XXX	51Z-4 MARKER RECEIVER
622-2921-XXX	860E -5 DME
622-2920-XXX	860E -4 DME

Honeywell(Bendix/King)

064-01017-XXXX	KAC952 HF COUPLER
064-01016-XXXX	KCU951 HF CONTROLLER
064-01015-XXXX	KTR953 HF TRANSCEIVER
071-01274-XXXX	KFS594 HF CONTROLLER
065-0053-00	TO -07 KAS297A ALTITUDE ALERTER
064-01052-XXXX	KY96A VHF COMM
064-01051-XXXX	KY97A VHF COMM
064-01054-XXXX	KY196A VHF COMM
064-01053-XXXX	KY197A VHF COMM
064-01019-XXXX	KY196 VHF COMM
064-01021-XXXX	KY197 VHF COMM
069-01028-XXXX	KX125 NAV/COMM
069-01024-XXXX	KX155 NAV/COMM
069-01032-XXXX	KX155A NAV/COMM
069-01025-XXXX	KX165 NAV/COMM
069-01033-XXXX	KX165A NAV/COMM
069-01019-XXXX	KX175B NAV/COMM

069-01021-XXXX	KY195B VHF COMM
069-01029-XXXX	KLX135/A GPS/COMM
066-04031-XXXX	KLN90B GPS RECEIVER
066-01148-XXXX	KLN89B GPS RECEIVER
066-01067-XXXX	KN53 NAV RECEIVER
066-04009-XXXX	KN72 NAV CONVERTOR
066-01033-XXXX	KN73 G/S RECEIVER
066-01063-XXXX	KN75 G/S RECEIVER
066-04004-XXXX	KN77 NAV CONVERTOR
066-03046-XXXX	KI525A NAV INDICATOR
066-03034-XXXX	KI203-207 NAV INDICATOR
066-03056-XXXX	KI208-209 NAV INDICATOR
066-03021-XXXX	KI226 RMI
066-03038-XXXX	KI229 RMI
066-03060-XXXX	KNI582 RMI
066-04008-XXXX	KNS80 AREA NAV
066-04010-XXXX	KNS81 AREA NAV
066-01064-XXXX	KN62 DME
066-01070-XXXX	KN63 DME
066-01088-XXXX	KN64 DME
066-01069-XXXX	KDI572-574 DME INDICATOR
066-01062-XXXX	KT76A TRANSPONDER
066-01156-XXXX	KT76C TRANSPONDER
066-01053-XXXX	KT79 TRANSPONDER
066-01141-XXXX	KT71 TRANSPONDER
066-01072-XXXX	KR87 ADF RECEIVER
066-03063-XXXX	KI227 ADF INDICATOR
066-03059-XXXX	KI228 ADF INDICATOR
066-01061-XXXX	KRA10/A RADAR ALTIMETER
066-03050-XXXX	KI250 R.ALT INDICATOR
066-01048-XXXX	KRA405 RADAR ALTIMETER
066-03031-XXXX	KNI415 R.ALT INDICATOR
066-03044-XXXX	KNI416 R.ALT INDICATOR
064-01023-XXXX	KTR908 VHF COMM
066-01078-XXXX	KNR634/A NAV RECEIVER
066-01077-XXXX	KDF806 ADF RECEIVER
066-01071-XXXX	KXP756 TRANSPONDER
066-01066-XXXX	KDM706/A DME
071-01215-XXXX	KFS598 COMM CONTROLLER
071-01282-XXXX	KFS598A COMM CONTROLLER
071-01216-XXXX	KFS564 NAV CONTROLLER
071-01283-XXXX	KFS564A NAV CONTROLLER

071-01210-XXXX KFS586 ADF CONTROLLER
071-01284-XXXX KFS586A ADF CONTROLLER
071-01192-XXXX KFS576 XPDR CONTROLLER
071-01276-XXXX KFS576A XPDR CONTROLLER

Honeywell

7001840-XXX RT300 RADIO ALTIMETER

Avtech

5061-1 AUDIO CONTROL PANEL

Becker

AR3201 VHF COMM
AR4201 VHF COMM
ATC4401-1 TRANSPONDER
ATC4401-2 TRANSPONDER
ATC2000-2 TRANSPONDER
ZVG2002 HOMER

Narco

MX12D NAV/COMM
COM810 VHF COMM
COM811 VHF COMM
AT150 TRANSPONDER
DME890 DME